




Curtain PIR with LED lighting (PL-10)

Product Description

PL-10 is a security and lighting sensor which generates security alarm signal at the same time turns on the LED light. It can be installed at the entrance, passage, room & stair etc... for lighting purpose. Ambient light level & timer are adjustable for different needs.




1. Specification Highlight

- Dual elements pyro detector
- For both security and lighting application
- Adjustable mounting angle
- Tamper Switch Included

2. Technical Specification


- ◆ Detection Pattern: Curtain
- ◆ Max. Mounting Height: 5 meter
- ◆ Alarm Duration: More than 5 second
- ◆ Input Voltage: 10-15VDC
- ◆ LED Brightness: 5 Lux at 2 meter distance
- ◆ Ambient Light Level Adjustment: 10 lux – infinite
- ◆ Timer Adjustment: from 5 sec to 5 min
- ◆ Operating Current: LED (65mA), Standby (8mA)
- ◆ Operating Temp.: -30C to +50C
- ◆ Operating Humidity: 95% at 25C
- ◆ Dimension: 90 x 48 x 40 mms
- ◆ Weight: 60g

3. Mounting position and detection pattern



Picture 1


4. Detection Pattern




Picture 2

5. Installation Instruction

5.1 Press at the spot as arrow indicates and pull out the back cover.




5.2 Mount the back cover onto the wall/ceiling by screws at the desired location.



5.3 Connect the wire according to the figure below:

- Tamper Signal
- Alarm Signal
- Power (12V)

For LED lighting only – connect wires to 12 V terminals. Refer Section 7 for jumper connection.



5.4 Close the housing after wiring is completed.

6. Lighting Application

6.1 Jumper Setting :

Jumper#	Function
1 & 2	LED Lighting On/Off

6.2 Ambient Light / Timer Setting

LUX Level

- Light turns on at dark when motion detected
- Light turn on whenever motion is detected

TIME: 5 seconds to 5 minute



7. Walk test procedures

7.1:

- Short circuit jumper #1 & #2.
- Power up the sensor and the LED will turn on for 2 min.
- Walk test within the detection range at 0.5 to 1 m/s speed. LED Indicator will turn on to indicate alarm condition.

Note: Set LUX to desired level to turn on light when motion is detected.

7.2 Sensor should be installed in open area away from trees, curtain & and possible moving object to avoid false alarm.

